



## WHEEL TORQUE EXTENSION & IMPACT SOCKET SET

The Wheel Torque Extension & Impact Socket Set has been developed so the output load can be accurately controlled in order to tighten wheel nuts to required specifications. This, in turn, helps prevent distortion and damage to wheels, associated components and brake mechanisms. Torque Master sockets and extensions are colour coded for easy identification and come in various sizes.

### Features:

- Colour coded for easy size identification
- Heavy duty construction
- 1/2" drive to fit any 1/2" socket (including thin wall sockets)
- Also available individually



WB	
31408	Torque extensions: 31400-B, 31400-F, 31400-G, 31400-Y Thin wall deep impact sockets: 31300-A, 31300-B, 31300-C, 31300-D

## TORQUE MASTER WHEEL TORQUE SOCKET BARS



WB				
31500-A	13/16"	100ft.lbs.	135Nm	Brown
31500-B	21mm	80ft.lbs.	110Nm	Orange
31500-C	19mm	100ft.lbs.	135Nm	Grey
31500-D	21mm	60ft.lbs.	80Nm	Black
31500-E	19mm	80ft.lbs.	110Nm	Blue
31500-F	19mm	65ft.lbs.	90Nm	Yellow
31500-G	17mm	80ft.lbs.	110Nm	Red
31500-H	17mm	55ft.lbs.	75Nm	Dark green
31500-I	7/8"	120 ft.lbs.	165Nm	White
31500-J	1"	140 ft.lbs.	190Nm	Grey
31500-K	17mm	110 ft.lbs.	150Nm	Purple
31500-L	1"	170 ft.lbs.	230Nm	Light green
31500-Q	7/8"	140 ft.lbs.	190Nm	Aqua
31500-T	15/16"	135 ft.lbs.	175Nm	Bright green
31500-Y	7/8"	100 ft.lbs.	135Nm	Navy blue
31500-Z	7/8"	65 ft.lbs.	90Nm	Tan
<b>31505</b> <i>5-piece kit designed specifically for the Australian market.</i>	13/16" 21mm 21mm 19mm 19mm	100ft.lbs. 80ft.lbs. 60ft.lbs. 80ft.lbs. 65ft.lbs.	135Nm 110Nm 80Nm 110Nm 90Nm	Brown Orange Black Blue Yellow
<b>31508</b> <i>8-piece kit to suit domestic and imported cars and light trucks.</i>	13/16" 21mm 21mm 19mm 19mm 19mm 17mm 17mm	100ft.lbs. 80ft.lbs. 60ft.lbs. 80ft.lbs. 65ft.lbs. 100ft.lbs. 80ft.lbs. 55ft.lbs.	135Nm 110Nm 80Nm 110Nm 90Nm 135Nm 110Nm 75Nm	Brown Orange Black Black Blue Yellow Grey Red Dark green

All sockets and extensions have a 1/2" female drive.